



Wired Long-Range RF Transmitter

HL-951T1-SWQ (917MHz)

Installation Manual



The ENFORCER HL-Series RF transmitters and receivers offer significantly increased range with greatly increased immunity to interference, whether physical obstacles, temperature extremes, or other environmental factors. The wired transmitter allows you to easily make other devices wireless.

-
- Includes one 3VDC lithium battery (CR-2032)
 - May also be powered by an external 4.5~13 VDC external regulated adapter (not included)
 - Frequency – 917MHz*
 - Operating range up to 1,800ft (550m)[†]
 - Over 2.028×10^{31} possible codes
 - LED transmission and low-battery indicator
 - Compatible with all SECO-LARM HL-series receivers of the same frequency
 - Also available without logo – HL-951T1-SWUQ

*868MHz also available with CE certification

[†]Actual range will vary depending on the installation and operating environment

SECO-LARM®


Specifications

Type		Wired RF transmitter
Wiring	Switch	Two 6" N.O. blue wires
	Power	Two 6" wires (red +, black -)
Power	Battery	1x 3VDC button battery (CR-2032, included)
	External	4.5~13 VDC regulated adapter
Battery life		Up to 10 years*
RF Frequency		917MHz [†]
Operating range		up to 1,800ft (550m) [‡]
# of Buttons		1
Channels		1
Code combinations		Over 2.028×10^{31} possible codes
Dimensions		$3\frac{1}{16}" \times 1\frac{5}{16}" \times \frac{1}{2}"$ (78x34x13 mm)

*Calculated based on ten 1-second button presses per day. [†]868MHz also available which has CE certification

[‡]Actual operating range will vary based on installation and operating environment

Dimensions



Installation

External Switch Connection

To control a device wirelessly, install an ENFORCER HL-series RF receiver to the device to be controlled and use the ENFORCER HL-951T1-SWQ transmitter to control it remotely. The wired transmitter can control the remote device directly or attached to an external N.O. switch* (a button, contact, or sensor). If installed to an external switch, the switch can have sole control (with the transmitter button disabled), or either the external switch or the transmitter can control the remote device (see also the *Installation Notes* on the following page).

NOTE: The transmitter is shipped with a *battery pull tab*. Before first use, open the case and pull the exposed end of the tab to remove and discard it, then reassemble the case.


Using the Transmitter's Built-In Button

The transmitter can be used alone with its battery or with an external regulated power adapter* (see Fig. 1).

If using an external power adapter, the battery may be removed or serve as a backup in case of power failure.

NOTE: Any unused wires must be insulated against any accidental contact to avoid a short circuit.

Fig. 1 Built-in button



†Insulate unused wires


‡AC Adapter optional

Using an External Switch with Sole Control

An external N.O. switch* (e.g., a button such as an RTE, a contact, or a sensor) may be connected inline so that the transmitter functions solely as an RF wireless add-on to the external switch. This requires the use of an external regulated power adapter*.

1. Remove the battery.
2. Connect the blue wires together.
3. Connect the N.O. switch inline between the external power adapter and transmitter as shown in Fig. 2.

Fig. 2 External inline power-on switch



†Connect the blue wires. The battery must be removed in this situation.

NOTE: If connected to an external power-on switch, you must remove the battery to disable the built-in button so that it can only be controlled by the power-on switch (see Fig. 2).

*External switch and regulated power adapter not included.


Installation – External Switch Connection (Continued)

Using an External Switch and the TX Button

If you desire to have the option of using either the external switch or the transmitter button to control the remote device, connect as follows (see Fig. 3).

1. Connect the external N.O. switch to the blue wires.
2. Connect the regulated power adapter positive (+) to the transmitter red wire and negative (–) to the transmitter black wire.
3. Do not remove the transmitter battery, if you wish to allow the transmitter button to also control the remote device.

Fig. 3 External switch and built-in button



†AC Adapter optional. If not used, insulate red and black wires.

INSTALLATION NOTES

- Any wires not in use must be insulated to avoid a short-circuit.
- Do not let the red wire touch any other wire. Doing so may burn out the transmitter.
- If using an external power adapter, the factory-installed lithium CR-2032 battery will serve as a backup in case of power interruption (Battery must be removed for external inline power-on switch).

Power Connection

The HL-951T1-SWQ can be powered by the factory preinstalled 3VDC lithium battery (CR-2032) or by an external 4.5~13VDC output regulated adapter (not included).

When using an external power adapter, correct polarity is imperative. Connect the transmitter's red wire to the adapter's positive output and the black wire to the adapter's negative output (see Figs. 1 and 2, on the previous page and Fig. 3 above).

NOTES

- The power input range of the wired transmitter is 4.5~13VDC and is polarity sensitive. Connecting more than 13VDC or reversing the polarity will burn out the unit and void the warranty.
- Use only "regulated" adapters to power the wired transmitter.
- The LED indicator will flash slowly when the button is pressed to indicate a low battery.

Important Warning – Coin Battery

WARNING!

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- The compatible battery type: CR2032
- Nominal battery voltage: 3VDC
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 158° F (70° C), or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and –).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Troubleshooting

Range is diminished

- Check the battery if not using an external power source. Change to a fresh battery if needed.
- Check for interference or obstructions.

Accessories Available from SECO-LARM

HL-Series 1-Channel Receiver



HL-951R1-SQ

HL-Series 2-Channel Receiver



HL-951R2-SQ

3VDC Lithium Battery (CR-2032)



X-930-096

FCC COMPLIANCE STATEMENT (HL-951T1-SWQ)

FCC ID: K4E951T1SW

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

IMPORTANT: Users and installers of this product are responsible for ensuring that the installation and configuration of this product complies with all national, state, and local laws and codes. SECO-LARM will not be held responsible for the use of this product in violation of any current laws or codes.

California Proposition 65 Warning: These products may contain chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.

NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2024 SECO-LARM U.S.A., Inc. All rights reserved.

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606
Phone: (949) 261-2999 | (800) 662-0800

Website: www.seco-larm.com
Email: sales@seco-larm.com



PITSW1

MI_HL-951T1-SWQ_WEB_240729.docx