

Wedge-Lock Instructions:

1. Place Connector in each end of Pipe or Tube until it makes contact with the Wedge-Lock's ribs.
2. Insert wedge into groove of Wedge-Lock and hammer into place.
3. The Wedge-Lock will expand against the material wall to properly lock and align the Pipe or Tube.
4. Weld the joint solid and grind smooth.

