



How to use the Tension Gauge



Attach to cable



Pull to engage spring hook, release lanyard.



Read the chart on label to find the tension ([Tension Chart](#) below)

TENSION CHART

SCALE*	CABLE DIAMETER/ TENSION (lbs)		
	1/8" CABLE	3/16" CABLE	1/4" CABLE
14	200 lbs		
15	225 lbs		
16	250 lbs		
17	275 lbs		
18.5	300 lbs		
19	325 lbs		
20	350 lbs		
21	375 lbs	200 lbs	
21.5	400 lbs		
23.5		250 lbs	
25.5		300 lbs	
27.5		350 lbs	
28.5		400 lbs	
31			200 lbs
33			250 lbs
35			300 lbs
36.5			350 lbs
38			400 lbs

*Read from above