

Splash Screen Loader

You can personalize the startup screen on your NexGen™, Luminex® II, Luminex, Diamante®, Luminex Captioner/Student Edition or Wave® writing machine by loading a photograph that has been saved as a JPG (or JPEG) file type. The photograph will display when turning your steno machine On. NexGen™ and Luminex II allow the startup screen photograph to also be used as a screen saver image. Please view NexGen User Guide and Luminex II User Guide for details on how to enable a screen saver on the NexGen™ and Luminex II.

There are stock photos provided in the Stenograph® Utilities Files folder that you downloaded and installed. The stock photos are located in the Splash Photos folder. You need to have the Stenograph Writers USB Drivers installed on your computer to load a new photograph on the writer. Follow these steps:


1. Turn your computer On and make sure it is fully booted.
2. Turn your steno machine On.
3. Plug your steno machine's USB cable into your computer's USB port and the other end of the USB cable into the steno machine's USB port.
4. Navigate to the location where you downloaded and installed the Stenograph Writer Utility files. At the Stenograph Writer Utility dialog, click the Utility button, double click the Utilities and Splash Photos folder and then double click the SplashLoader.exe. The Writer Splash Screen Loader dialog box displays.




5. To select a photograph or picture stored in a JPEG format, click  to browse. Navigate to the location where the JPG is stored. Highlight the picture's name and click **OK**. To select one from the sample pictures, double click the Splash Photos folder and select a picture.

Splash Screen Loader

- The Writer Splash Screen Loader dialog box displays the path and the name of the selected picture. To load the picture on your steno machine, click Load.



- When the picture is sent, a Success dialog box displays on your computer.



- Click **OK** to close the confirmation dialog box. Click **Quit** to close the Splash Screen loader program.
- To see your selected picture displayed on your steno machine, turn Off the steno machine and turn it back On. The startup screen displays your selected picture.