

VERSION A, REV. 00

FEEDER BREAKER SPARE PARTS

IMPORTANT INFORMATION:

McLanahan Corporation recommends that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLanahan Corporation** stocks a wide variety of commonly used components; however storing these parts at your facility will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLanahan Corporation** for price and availability of all parts for your McLanahan equipment.

RECOMMENDED STANDARD SPARE PARTS:

QUANTITY	DESCRIPTION
1	Tail Shaft Assembly
1	Head Shaft/ Bearing Assembly
36	Breaker Bit
36	Breaker Bit Block
2	Spherical Roller Bearing
2	Tapered Bearing Adapter
4	Seal
9	Retaining Ring
5	Flight Bar
10	Chain, Extended Link
10	Chain, Plain Link
10	Chain, Block Link
30	T-Head Cotter Pin

Recommended Spare Parts (continued)

QUANTITY	DESCRIPTION
2	Filter Element (in tank)



FEEDER BREAKER SPARE PARTS LIST

VERSION A, REV. 00

2	Suction Strainer
1	Vent Breather
1	Shuttle Valve
1	Filter Element (Charge)
2	Temperature Switch, Explosion-Proof
1	Pressure Switch, Explosion-Proof
1	Speed Monitor
1	Sensor, Liquid Level
1	Cordset, Extreme Duty
1	Proximity Sensor
1	Fluid Coupling

Please contact our Parts & Service Department for current Pricing and Lead Times.