

JAW CRUSHER SPARE PARTS

IMPORTANT INFORMATION:

McLanahan Corporation recommends that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLanahan Corporation** stocks a wide variety of commonly used components; however storing these parts at your facility will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLanahan Corporation** for price and availability of all parts for your McLanahan equipment.

RECOMMENDED STANDARD SPARE PARTS:

<u>DESCRIPTION</u>
Lower Level Stock:
Toggle Plate and Toggle Seat
Tension Rod Assemblies
Moveable Jaw Die Wedge, Key & Heel Wedge bolts/washers/nuts.
Higher Level Stock:
<i>All above items</i>
Stationary Jaw Die with Key/Heel Wedge Plates
Moveable Jaw Die with Pitman Wedges

Please contact our Parts & Service Department for current Pricing and Lead Times.