

# **SAND MANAGER® CLASSIFYING TANK**

## **SPARE PARTS**

### **IMPORTANT INFORMATION:**

It is recommended that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLanahan Corporation** stocks a wide variety of commonly used components; however, storing these parts at your facility, will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLanahan Corporation** for price and availability of all parts for your **McLanahan** equipment.

### **RECOMMENDED STANDARD SPARE PARTS:**

<b><u>QUANTITY</u></b>	<b><u>DESCRIPTION</u></b>
3	Valve Seat
3	Valve
3	Elbow
6	Retaining Spline
3	Bin-Level Indicator
3	Bin-Level Indicator Paddle
3	Hydraulic Cylinder
3	Solenoid Valve
3	Hex Coupling Nut
1	Valve Rod Rubber Hose
1	CPU (Optional)
1	Input Card (Optional)
1	Output Card (Optional)
1-Set	V-Belts (Only required with optional Recirculating Pump System)
1-Set	Bearings (Only required with optional Recirculating Pump System)
1	Bronze Bushing (Only required with optional Recirculating Pump System)
1	Impeller (Optional-Only required with optional Recirculating Pump System)



**SAND MANAGER®**  
**CLASSIFYING TANK**  
**SPARE PARTS**

VERSION A, REV. 01

1	Impeller Bottom Housing (Optional-Only required with optional Recirculating Pump System)
1	Pump Shaft (Optional-Only required with optional Recirculating Pump System)

*Please contact our Parts & Service Department for current Pricing and Lead Times.*