

# QUICK START GUIDE - R 10

THANK YOU FOR PURCHASING THE COMPUTER.

THIS GUIDE PROVIDES A QUICK SETUP OF YOUR COMPUTER.

# DURABOOK

## Package Contents

Tablet PC



AC adapter & power cord



Stylus & tether



Stylus holder & screws




Li-ion Battery



Standard configuration items.

## 1. Install The Battery

Align and insert the battery into the compartment. Slide the latch to the lock position to secure the battery.



## 2. Connect The AC Adapter

The AC adapter powers up the device and charges the battery.



## 3. Power On

Click the power button.



## Install The Stylus Holder

Align and secure the stylus holder on the right side of the tablet PC with the supplied screws.




NOTE: For more information, see User Manual on the device or at [durabook.com/support](http://durabook.com/support).


# QUICK START GUIDE - R10

# DURABOOK


Barcode or USB 3.2 Type A or USB 3.2 Type C or RS232 or RJ45 (optional)



RF Pass-thru connector (optional) Docking connector




Front camera  
Microphone  
Camera cover  
Microphone  
Ambient light sensor




Camera LED flash Rear camera (optional)

Battery compartment Speaker Fingerprint scanner (optional)




Program button (P1/P2) Copilot button Up/Down bttons



Audio combo jack  
RJ45  
USB 3.2 port  
Thunderbolt 4  
DC-in jack

Battery latch release button Nano SIM card slot MicroSD card slot



Mounting slot for stylus holder  
Program button (P)  
Power button

62+009715+00