

Baby Lock Stitch Guide

BLES8-QG2

Usage Instructions

Stitch Guide can be attached to the left or right side.


1. Loosen the fixing screw located on the back of the presser foot holder.
2. Insert the straight end of the Stitch Guide into the right side or left side of the hole opening.
3. Adjust the guide to desired position.
4. Tighten the screw and start sewing slowly.

* (BLC4) Fixing screw are packed in the built-in accessory compartment.


NOTE: Turn handwheel several times, to be sure moving parts do not touch the Stitch Guide.




Left Side



Right Side



How To Attach



★ **Presser Foot Holder**

baby lock

FOR THE LOVE OF SEWING

www.BabyLock.com

Baby Lock Guide Couture

BLES8-QG2

Instructions d'utilisation

Le guide couture peut être fixé sur le côté gauche ou droit.


1. Desserrez la vis de fixation située à l'arrière du support du pied-de-biche.
2. Insérez l'extrémité droite du Guide de Point dans le côté droit ou gauche de l'ouverture (trou) du support du pied-de-biche.
3. Ajustez le guide à la position désirée.
4. Serrez la vis et commencez à coudre à une vitesse lente.

* (BLC4) Les vis de fixation sont emballées dans le compartiment d'accessoires intégré.

REMARQUE: Tournez plusieurs fois le volant, pour vous assurer que les pièces mobiles ne touchent pas le Guide de Point.




Comment le fixer




★ Presser Foot Holder

Côté gauche



Côté droit



baby lock

FOR THE LOVE OF SEWING