


If using MODEM II, MODEM IIe or MODEM IIle2 Reporting Formats

When the fire alarm control panel (FACP) is reporting with the formats **MODEM II**, **MODEM IIe** or **MODEM IIle2**, the **SLE-MF-JMP** jumper must be inserted into **J8** (with the white line towards the left side of the Dual Path communicator as shown below).

Do NOT insert jumper when the FACP uses other reporting formats.



SLE-MF-JMP Jumper

