


RMC Setup

1. Go to rmc.specotech.com
2. You will need to create a username and password.



RMC[®]
SMART & SIMPLE

Remote Management Connection™ Service
Access your device any where any time

Login

Username

Password

Login

[Register an Account](#)
[Forget Password?](#)

Windows Android iPhone iPad MAC

RMC Setup

3. Select register an account. Once registered you will log back in to RMC.

RMC®
SMART & SIMPLE
Remote Management Connection™ Service
Access your device any where any time

Register an Account

Username

Password

Confirm Password

Email

Description

Register

[Login Page](#)
[Forgot ID or Password?](#)

RMC Setup

4. Select Device Management

RMC[®]
SMART & SIMPLE

Dashboard

Device Management

Dashboard

User Info

Full Name	speco	Identity	Member
Device Total	1	Login Total	136
Login Time	2020-01-28 02:19:26	Login Address	United States / New York / Lindenhurst
Login device	PC	Login IP	108.30.94.35
Last Login Time	2020-01-28 01:36:46	Last Login Address	United States / Arizona / Phoenix
Last Login device	PC	Last Login IP	173.129.185.132

RMC Setup

5. Select Add

RMC[®]
SMART & SIMPLE

Dashboard

Device Management

Device Management

Device List

AddDelete

DescriptionMAC AddressPlease Select ProductPlease Select Model

TypeVersionPlease Select HttpsAddress


PortSearchClear

No.	Description	MAC Address	Product	Model	Type	Version	Https	Address	Port	Secure	Status	Edit	
-----	-------------	-------------	---------	-------	------	---------	-------	---------	------	--------	--------	------	--

specoaccess

RMC Setup

6. Enter Server IP mac address.



The screenshot displays the RMC (SMART & SIMPLE) Device Management interface. On the left is a dark sidebar with a logo and navigation links for 'Dashboard' and 'Device Management'. The main content area has a header 'Device Management' and a '+ Device Add' button. Below this, there are two radio buttons: 'Device ID' and 'MAC Address', with the latter being selected. A text input field to the right of these buttons contains the MAC address '5C:F2:07:58:00:9E'. A blue arrow points from the instruction text to this input field. A 'Search' button is located at the bottom right of the form, and a 'Device List' link is in the top right corner.

RMC[®]
SMART & SIMPLE

Dashboard
Device Management

Device Management

+ Device Add

Device ID ☐ MAC Address ☒

5C:F2:07:58:00:9E

Search

Device List


RMC Setup

7. Once you find your device, you can enter a description and select save.

Device ID ☐ MAC Address ☒	5C:F2:07:58:00:9E
Search	
No.	127
MAC Address	5c:f2:07:58:00:9e
Product	1 Door
Model	Corporate
Type	36
Version	5.00-02d
Https	Http
IP Address	192.168.56.51
Port	80
Description	Rep Demo Site
Save Cancel	

RMC Setup

- Now you will see your site or sites listed.
- Select link and that will be the address you provide your customer to use to connect to their site.



The screenshot shows the RMC (Smart & Simple) Device Management interface. The left sidebar contains 'Dashboard' and 'Device Management'. The main area is titled 'Device Management' and contains a 'Device List' section. Above the table are search filters for Description, MAC Address, Product, Model, Type, Version, Https, Address, and Port, along with 'Search' and 'Clear' buttons. The table has columns: No., Description, MAC Address, Product, Model, Type, Version, Https, Address, Port, Secure, Status, Edit, and a checkbox. One entry is listed: 'Rep Demo Site' with a 'Link' button. Below the table, it says 'Showing 1 to 1 of 1 entries' and has 'Previous', '1', and 'Next' navigation buttons.

No.	Description	MAC Address	Product	Model	Type	Version	Https	Address	Port	Secure	Status	Edit	
127	Rep Demo Site	5c:f2:07:58:00:9e	1 Door	Corporate	36	5.00-02d	Http	192.168.56.51	80	Link	Online	Edit	☐

RMC Setup

10. Log into your server and under system settings, go to network settings and select RMC.


The screenshot displays the 'System Settings' interface of the Speco Technologies system. The interface is organized into a grid of categories, each with a list of sub-settings. A blue arrow points from the instruction text to the 'RMC' option under the 'Network Setting' category.

System Settings

- System Setting**
 - Dashboard
 - Dashboard Setting
 - Report
 - Smart Report Setting
 - Log Management
 - Device Setting
 - Door
 - Elevator
 - Aux Input
 - Aux Output
 - Elevator Action
 - Controller
 - Region
 - NVR
 - NVR Setting
 - NVR Channel
 - Video Tag Setting
 - User Setting
 - User Def. Field
 - User Role
 - Web User Account
 - Client & Site
 - Client Management
 - Client Replacement
 - Site Management
 - Site Device
 - Administration
 - Card Format
 - Floor
 - Floor Setting
 - Group Table
 - Card Holder Group
 - Door Group
 - Access Level Group
 - Event Action
 - Event Action
 - Event Code
 - System Setting
 - Update
 - Backup
 - Restore
 - Save Data
 - Reboot
 - Factory Default
 - Threat Level
 - Threat Level Setting
 - Network Setting
 - IP Address
 - FTP
 - SMTP
 - Time Server
 - RMC**
 - Link
 - OpenAPI


RMC Setup

11. Select edit.



RMC Setup

12. Enable RMC and select save.



The screenshot shows the 'speco technologies' logo in the top left corner. A dark blue navigation bar at the top contains icons for various system functions. Below this, a breadcrumb trail reads 'Network Setting > RMC'. The main content area is titled 'Basic' and contains a single configuration item: 'Connect to RMC' with a checked checkbox. At the bottom right of this section are three buttons: 'Save', 'Reset', and 'Cancel'. A blue arrow originates from the text '12. Enable RMC and select save.' and points directly to the 'Save' button.