




The taps closest to the center are for 25V wiring.

The taps closest to the outer edge are for 70V wiring.

Use the yellow wire connected to the white connector to choose your speaker wattage.

In the example below, the speaker is wired 1W at 70V.



To wire the speaker to the amplifier, another speaker, or the SPG6MTCAN, simply push the “N” tab and insert the negative wire on the terminal and push the “L” tab and insert the positive wire on the terminal.



For more information visit specotech.com or call 1.800.645.5516