



# Yale Assure Lever®

## Touchscreen (YRL226) and Key-Free Touchscreen (YRL256)

### Installation and Programming Instructions

This manual will walk you through all the required steps to add your new Yale Assure Lever to your door.


- Remove existing door knob or lever
- Double check door measurements
- Install your Assure Lever
- Program your Assure Lever
- Add your Assure Lever to your smart home system or Yale Access app if purchased with Yale Smart Module or Yale Access Upgrade kit

#### Tools Needed



Standard  
Phillips Head  
Screwdriver

#### Tools Needed For New Doors Or Adjusting Existing Door



Drill



Utility  
Knife




Pencil



Wood  
Mortise  
Chisel



Tape  
Measure



Level

#### Before you begin

DOWNLOAD  
THE BILT APP  
**BILT.**



Using the app on your smart phone, scan this QR for step-by-step installation instructions & to register your lock



#### WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm.  
For more information go to [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov).

Failure to follow these instructions could result in damage to the product, voiding the factory warranty and could lead to failure of the product to provide access.




# What's In The Box



Touchscreen  
Keypad



Key (YRL226)



Cylinder  
(YRL226)


OR




Key-Free  
Cylinder  
(YRL256)




Yale Smart Module  
(not included with  
NR models)




Installation Guide  
and Door Template




Inside Lock




Battery Cover



AA Alkaline  
Batteries



Mounting Plate




Levers




Battery  
Cover  
Key

## Mounting Hardware



Strike Plate



Latch  
(AYRL-DRIVE  
Adjustable Drive-In Latch  
available for purchase)



**x4**

#7 wood & #8-32  
Machine x 20mm  
Combination Screws




**x2**

#8-32 x 5/16"  
Machine Screws



**x2**



M4 x 22mm  
Pan Head Machine  
Screws



# Remove Existing Door Knob or Lever



Do not discard old lock hardware until Assure Lever has been successfully installed.




# 2

## Check Door Measurements And Make Adjustments If Needed



### Door Checker

Use door checker from installation guide envelope to verify your door measurements and make any needed adjustments.



### New Door Marking Template

With the door checker, use the template from installation guide envelope to prep a new door that has not been predrilled for hardware.




# 3

## Install Latch and Strike Plate Right Hand Installation Shown






x4

Actual Size





AYRL-DRIVE  
Adjustable Drive-In Latch  
available for purchase






# 4

## Install Touchscreen Keypad Right Hand Installation Shown



# 5

## Install Inside Mounting Plate Right Hand Installation Shown



# 6

## Attach Cable Right Hand Installation Shown

