



All dimensions shown are in millimetres

Construction: **internal - copper/aluminium honeycomb/graphite**
external - aluminium panels

Connections: **1.2m long flying lead (2 core)**

Model	Height ± 2mm	Width ± 2mm	Finish	Output Watts	Weight kg
FZB-120-042/GF	1156	430	painted	350	6.2
FZB-150-042/GF	1476	435	painted	500	8.5
FZB-180-042/GF	1796	441	painted	500	14.6
FZB-180-052/GF	1796	540	painted	750	16.9
FZB-180-072/GF	1796	740	painted	1000	20.7

Issue 1.0



Tools & Material Required

Tape measure
Screwdriver - crosshead & flathead
Pliers
Electric drill
Masonry drill bit
Spirit level
Stepladder (for taller radiators)

Key	Component	Qty
A	Boss	4
B	Wall Plug	4
C	Bracket	4
D	Screw, 6mm dia x 50mm	4
E	Washer	4
F	Grub Screw	4
G	Allen Key	1

Assembly Instructions

- Screw bosses (A) to fixings on the back of the radiator.
- Accurately mark out bracket holes on wall using spirit level.
- Drill four holes to a minimum depth of 65mm & insert wall plugs (B).
- Attach brackets (C) to wall with screws (D) & washers (E).
- Hang radiator onto wall by inserting bosses (A) into brackets (C).
- Tighten grub screws (F) with Allen key (G).

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.

